

Q

Are Tamron tele converters for Canon compatible with Canon cameras?

A

Tamron tele converters for Canon can be used in the following combinations.

It cannot be used with other lenses.

AF: Autofocus can be used.

AF (F8): AF points compatible with a maximum aperture of f/8 or faster.

MF: Only manual focus can be used.

As of 03/2018

Lens	Tele Converter	Camera	
		AF (F8)	MF
SP 150-600mm G2 (Model A022) 100-400mm (Model A035)	TELE CONVERTER 1.4x (Model TC-X14)	EOS 80D, EOS 7D Mark II EOS 5D Mark IV, EOS 5Ds R, EOS 5Ds, EOS 5D Mark III EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS-1D Mark IV	EOS Kiss X80, EOS Rebel T6, EOS 1300D, EOS 8000D, EOS Rebel T6s, EOS 760D, EOS Kiss X8i, EOS Rebel T6i, EOS 750D, EOS Kiss X70, EOS Rebel T5, EOS 1200D, EOS Hi, EOS Kiss X7i, EOS Rebel T5i, EOS 700D, EOS Kiss X7, EOS Rebel SL1, EOS 100D, EOS Kiss X6i, EOS Rebel T4i, EOS 650D, EOS Kiss X5, EOS Rebel T3i, EOS 600D, EOS Kiss X50, EOS Rebel T3, EOS 1100D, EOS Kiss X4, EOS Rebel T2i, EOS 550D, EOS Kiss X3, EOS Rebel T1i, EOS 500D, EOS 70D, EOS 60D, EOS 7D EOS 5D Mark II, EOS 6D
	TELE CONVERTER 2.0x (Model TC-X20)	X	EOS Kiss X80, EOS Rebel T6, EOS 1300D, EOS 8000D, EOS Rebel T6s, EOS 760D, EOS Kiss X8i, EOS Rebel T6i, EOS 750D, EOS Kiss X70, EOS Rebel T5, EOS 1200D, EOS Hi, EOS Kiss X7i, EOS Rebel T5i, EOS 700D, EOS Kiss X7, EOS Rebel SL1, EOS 100D, EOS Kiss X6i, EOS Rebel T4i, EOS 650D, EOS Kiss X5, EOS Rebel T3i, EOS 600D, EOS Kiss X50, EOS Rebel T3, EOS 1100D, EOS Kiss X4, EOS Rebel T2i, EOS 550D, EOS Kiss X3, EOS Rebel T1i, EOS 500D, EOS 80D, EOS 70D, EOS 60D, EOS 7D Mark II, EOS 7D, EOS 5D Mark IV, EOS 5Ds R, EOS 5Ds, EOS 5D Mark III, EOS 5D Mark II, EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS 6D EOS-1D Mark IV

Lens	Tele Converter	Camera		
		AF	AF (F8)	MF
70-210mm F4 (Model A034)	TELE CONVERTER 1.4x (Model TC-X14)	EOS 6D Mark II, EOS 5D Mark IV, EOS 5D Mark III, EOS 5Ds R, EOS 5Ds, EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS 5D Mark II, EOS 6D EOS-1D Mark IV EOS 80D, EOS 7D Mark II, EOS 70D, EOS 60D, EOS 7D, EOS 9000D, EOS 77D, EOS Kiss X9i, EOS Rebel T7i, EOS 800D, EOS Kiss X9, EOS Rebel SL2, EOS 200D, EOS Kiss X80, EOS Rebel T6, EOS 1300D, EOS 8000D, EOS Rebel T6s, EOS 760D, EOS Kiss X8i, EOS Rebel T6i, EOS 750D, EOS Kiss X70, EOS Rebel T5, EOS 1200D, EOS Hi, EOS Kiss X7i, EOS Rebel T5i, EOS 700D, EOS Kiss X7, EOS Rebel SL1, EOS 100D, EOS Kiss X6i, EOS Rebel T4i, EOS 650D, EOS Kiss X5, EOS Rebel T3i, EOS 600D, EOS Kiss X50, EOS Rebel T3, EOS 1100D, EOS Kiss X4 , EOS Rebel T2i, EOS 550D, EOS X3 , EOS Rebel T1i, EOS 500D	—	—
	TELE CONVERTER 2.0x (Model TC-X20)	X	EOS 6D Mark II, EOS 5D Mark IV, EOS 5D Mark III, EOS 5Ds R, EOS 5Ds, EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS-1D Mark IV EOS 80D, EOS 7D Mark II, EOS 9000D, EOS 77D, EOS Kiss X9i, EOS Rebel T7i, EOS 800D, EOS 6D Mark II, EOS 5D Mark IV, EOS 5D Mark III, EOS 5Ds R, EOS 5Ds, EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS-1D Mark IV EOS 80D, EOS 7D Mark II, EOS 9000D, EOS 77D, EOS Kiss X9i, EOS Rebel T7i, EOS 800D,	EOS 5D Mark II, EOS 6D EOS Kiss X9, EOS Rebel SL2, EOS 200D, EOS Kiss X80, EOS Rebel T6, EOS 1300D, EOS 8000D, EOS Rebel T6s, EOS 760D, EOS Kiss X8i, EOS Rebel T6i, EOS 750D, EOS Kiss X70, EOS Rebel T5, EOS 1200D, EOS Hi, EOS Kiss X7i, EOS Rebel T5i, EOS 700D, EOS Kiss X7, EOS Rebel SL1, EOS 100D, EOS Kiss X6i, EOS Rebel T4i, EOS 650D, EOS Kiss X5, EOS Rebel T3i, EOS 600D, EOS Kiss X50, EOS Rebel T3, EOS 1100D, EOS Kiss X4 , EOS Rebel T2i, EOS 550D, EOS X3 , EOS Rebel T1i, EOS 500D EOS Kiss X5 (Rebel T3i, 600D), EOS Kiss X50 (Rebel T3, 1100D), EOS Kiss X4 (Rebel T2i, 550D), EOS X3 (Rebel T1i, 500D),

Lens	Tele Converter	Camera
		AF
SP 70-200mm G2 (Model A025)	TELE CONVERTER 1.4x (Model TC-X14)	EOS Kiss X80, EOS Rebel T6, EOS 1300D, EOS 8000D, EOS Rebel T6s, EOS 760D, EOS Kiss X8i, EOS Rebel T6i, EOS 750D, EOS Kiss X70, EOS Rebel T5, EOS 1200D, EOS Hi, EOS Kiss X7i, EOS Rebel T5i, EOS 700D, EOS Kiss X7, EOS Rebel SL1, EOS 100D, EOS Kiss X6i, EOS Rebel T4i, EOS 650D, EOS Kiss X5, EOS Rebel T3i, EOS 600D, EOS Kiss X50, EOS Rebel T3, EOS 1100D, EOS Kiss X4, EOS Rebel T2i, EOS 550D, EOS Kiss X3, EOS Rebel T1i, EOS 500D, EOS 80D, EOS 70D, EOS 60D, EOS 7D Mark II, EOS 7D, EOS 5D Mark IV, EOS 5Ds R, EOS 5Ds, EOS 5D Mark III, EOS 5D Mark II, EOS-1D X Mark II, EOS-1D X, EOS-1Ds Mark III, EOS 6D, EOS-1D Mark IV
	TELE CONVERTER 2.0x (Model TC-X20)	

- When shooting subjects with low contrast and/or luminosity values, the camera may be unable to focus.
- Photographic data such as focal length may be displayed incorrectly.
- Compatibility and performance with cameras other than those listed above are not guaranteed.